

Tone List

No.	Name	MSB	LSB	PC
1 SYNTH / PAD				
1	Saw Lead	87	0	1
2	Brite Square	87	0	2
3	Sync Lead	87	0	3
4	GR Lead	87	0	4
5	Jupiter Lead	87	0	5
6	Reso Saw Lead	87	0	6
7	Simple Tri	87	0	7
8	Sine Lead	87	0	8
9	Sqr Lead	87	0	9
10	Octa-Juice	87	0	10
11	Octa-Square	87	0	11
12	Vintager	87	0	12
13	Super Saw Pad	87	0	13
14	OB Strings	87	0	14
15	Poly Synth 1	87	0	15
16	Poly Synth 2	87	0	16
17	Poly Synth 3	87	0	17
18	Euro Express	87	0	18
19	Soft Pad	87	0	19
20	Hollow Pad	87	0	20
21	Phaser Pad	87	0	21
22	Heaven Pad	87	0	22
23	Cosmic Rays	87	0	23
24	Voyager	87	0	24
2 PIANO / KEYBOARD				
1	Grand Piano	87	0	25
2	E-Grand	87	0	26
3	JD Piano	87	0	27
4	Honky Tonk	87	0	28
5	Phase EP	87	0	29
6	Stage EP	87	0	30
7	FM EP	87	0	31
8	Wurly EP	87	0	32
9	Harpsichord	87	0	33
10	Phase Clav	87	0	34
11	Amped Clav	87	0	35
12	AX Clav	87	0	36
13	Pulse Clav	87	0	37
14	Celesta	87	0	38
15	Music Box	87	0	39
16	JUNO Bell	87	0	40
17	Fantasia	87	0	41
18	Dreaming Box	87	0	42
19	Vibraphone	87	0	43
20	Glodken	87	0	44
21	Marimba	87	0	45
22	Xylophone	87	0	46
23	Steel Drums	87	0	47
24	Santur Stack	87	0	48

No.	Name	MSB	LSB	PC
3 ORGAN / ACCORDION				
1	VK Organ 1	87	0	49
2	D-Bars 1	87	0	50
3	D-Bars 2	87	0	51
4	Jazz Organ 1	87	0	52
5	Rotary Org 1	87	0	53
6	Vintage Org 1	87	0	54
7	VK Organ 2	87	0	55
8	Jazz Organ 2	87	0	56
9	Rotary Org 2	87	0	57
10	Vintage Org 2	87	0	58
11	Old Fashion	87	0	59
12	JL Organ 1	87	0	60
13	JL Organ 2	87	0	61
14	Dist Org	87	0	62
15	Positive Org	87	0	63
16	Grand Pipes	87	0	64
17	Musette Acd	87	0	65
18	Accordion 1	87	0	66
19	It. Accordion 1	87	0	67
20	Accordion 2	87	0	68
21	It. Accordion 2	87	0	69
22	Harmonica 1	87	0	70
23	Blues harp	87	0	71
24	Harmonica 2	87	0	72
4 STRINGS / CHOIR				
1	Bright Violin	87	0	73
2	Bright Cello	87	0	74
3	Strings 1	87	0	75
4	Strings 2	87	0	76
5	Staccato	87	0	77
6	Pizzicato	87	0	78
7	JP Strings	87	0	79
8	Synth Str 1	87	0	80
9	Synth Str 2	87	0	81
10	106 Strings	87	0	82
11	JX Strings	87	0	83
12	Sawtooth Str	87	0	84
13	Tape Strings	87	0	85
14	Movie Scene	87	0	86
15	Vox Pad 1	87	0	87
16	Aerial Choir	87	0	88
17	Angels Choir 1	87	0	89
18	Synth Vox 1	87	0	90
19	Vox Pad 2	87	0	91
20	Synth Vox 2	87	0	92
21	Gospel Hum	87	0	93
22	Angels Choir 2	87	0	94
23	3D Vox	87	0	95
24	Jazz Doos	87	0	96

No.	Name	MSB	LSB	PC
5 BRASS / W WINDS				
1	Trumpet	87	0	97
2	Solo Tb	87	0	98
3	Breathy Sax	87	0	99
4	Soprano Sax	87	0	100
5	Alto Sax	87	0	101
6	Tenor Sax	87	0	102
7	Baritone Sax	87	0	103
8	Brass Section	87	0	104
9	Sax Section	87	0	105
10	Sousaphone	87	0	106
11	80s Brass 1	87	0	107
12	Soft SynBr	87	0	108
13	80s Brass 2	87	0	109
14	Analog Brass	87	0	110
15	Poly Brass	87	0	111
16	106 Brass	87	0	112
17	Octa Brass	87	0	113
18	Flute	87	0	114
19	Piccolo	87	0	115
20	Clarinet	87	0	116
21	Oboe	87	0	117
22	Pan Pipes	87	0	118
23	Shakuhachi	87	0	119
24	Tape Flute	87	0	120
6 GUITAR / BASS				
1	Nylon Gtr	87	0	121
2	Folk Gtr	87	0	122
3	Jazz E Gtr	87	0	123
4	Pick E Gtr	87	0	124
5	Dist Gtr	87	0	125
6	Searing Gtr	87	0	126
7	Fuzz Gtr	87	0	127
8	Aerial Harp	87	0	128
9	Sitar	87	1	1
10	Pick E Bs	87	1	2
11	Finger E Bs	87	1	3
12	Acoustic Bs	87	1	4
13	Slap Bs	87	1	5
14	Fat Analog	87	1	6
15	Moog Bs 1	87	1	7
16	Punch MG	87	1	8
17	Round Bs	87	1	9
18	Moog Bs 2	87	1	10
19	Acdg Bs	87	1	11
20	MKS SynBs	87	1	12
21	TB Dist Bs	87	1	13
22	Juno Squ Bs	87	1	14
23	Drums	87	1	15
24	Percussion	87	1	16

No.	Name	MSB	LSB	PC
Special Tone				
1	Synth 1 (Synth Lead)	87	64	1
2	Synth 2 (Poly Synth)	87	64	2
3	Synth Bass	87	64	3
4	Violin	87	64	4
5	Trombone	87	64	5
6	Jazz Scat	87	64	6

Drums (GUITAR / BASS No. 23)



Percussion (GUITAR / BASS No. 24)

